

Kelly KLS-RM series

Passenger Vehicle & Racing Sinusoidal BLDC Motor Controllers

User Manual

Devices Supported:

KLS7225RM	KLS7230RM	KLS7235RM	KLS7240RM	KLS7245RM
KLS7260RM	KLS7260RM			
KLS8425RM	KLS8428RM	KLS8430RM	KLS8445RM	KLS8460RM
KLS8480RM	KLS84100RM	KLS84120RM	KLS84150RMO	KLS84180RMO
KLS1270RMO	KLS1285RMO	KLS12100RMO	KLS12130RMO	KLS12160RMO
KLS1460RMO	KLS1475RMO	KLS1490RMO	KLS14110RMO	KLS14140RMO
KLS1680RMO	KLS16100RMO	KLS16130RMO		

Rev. 2.1.1
Dec. 2024

Contents

Chapter 1 Introduction.....	2
1.1 Overview.....	2
Chapter 2 Features and Specifications	3
2.1 General functions	3
2.2 Features	4
2.3 Specifications	5
2.4 Name Regulation.....	5
Chapter 3 Wiring and Installation	6
3.2 Connections.....	17
3.3 Installation Check List.....	23
Chapter 4 Configuration Program.....	24
4.1 Connecting to upper host.	25
4.2 How to use auto-Identification.	26
4.3 Program parameters and value	28
Chapter 5 Maintenance	35
Table 1: Error Codes.....	35
Contact Us:	37

Chapter 1 Introduction

1.1 Overview

KLS-RM is a variant of standard KLS controllers. KLS-RM has greatly enhanced its peak current, which is suitable for motor application scenarios that require high starting acceleration, such as racing electric motorcycles.

This manual introduces the features, installation, and maintenance of the Kelly sinusoidal brushless DC (BLDC) motor controller. Please read the manual carefully before using the controller. If you have any questions, contact the Kelly Controls support center.

The primary design focus is to address noise issues in BLDC motor drive applications. The KLS-RM motor controller must be used with Hall sensors and currently does not support sensor-less brushless motors.

Compared with the traditional trapezoidal control technology, this technology, based on sinusoidal drive technology, can reduce operating noise and switch loss by one-third, meeting the noise reduction and efficiency requirements of brushless DC motor applications. It uses high-power MOSFETs, SVPWM, and FOC, achieving up to 99% efficiency in most cases. A powerful microprocessor brings comprehensive and precise control to the controller. It also allows users to quickly and easily adjust parameters, conduct tests, and obtain diagnostic information. The KLS controller can be programmed on both PC software and Android App. The KLS-RM features user-friendly I/O terminals, allowing customers to easily connect the battery and motor.

Caution!

Before running the motor, please start the auto-identification operation first. And do not attempt to connect the controller to the user program or change settings in the user program or Android App while the motor is still running.

In other words, if you want to connect the controller to the user program or attempt to program, please stop the motor first. This is the first step you must take.

Chapter 2 Features and Specification

2.1 General functions

1. Extended fault detection and protection. Customers can read the error message in PC software or Android APP also.
2. Monitoring battery voltage. The controller will stop driving if the battery voltage is too high. When the battery voltage is low, it will progressively cut back motor drive power as the battery voltage drops. It will also stop driving if the battery voltage reaches the preset "Low Battery Voltage" value.
3. Built-in current loop and over current protection.
4. Configurable motor temperature protection range.
5. Current cutback at low temperature and high temperature to protect battery and controller. The current begins to ramp down at 90°C case temperature, shutting down at 100°C.
6. The controller keeps monitoring battery recharging voltage during regen braking.
7. Maximum reverse speed and forward speed can be configured between 20% and 100% respectively and separately.
8. The controller can be programmed and configured using user program or an Android app. For the PC side, please connect the controller and PC using a Kelly USB cable or a USB-RS232 set to use the user program. For the Android side, please connect the controller to a Bluetooth adapter which purchased from our site to use the configuration app on Android devices.
9. Provision of a +5 volt and +12 volt output to supply various kinds of hall sensors and switches.
10. Multiple switches inputs. By default, the switch is effective when the voltage value is 12V.
11. 3 analog inputs (signal is 0-5V), the default are throttle analog input, brake analog input, and motor temperature input.
12. The controller will copy the pulse signal of A-phase Hall sensor for use in the pulse speedometer.
13. Configurable boost function. Enables the maximum motor output if the boost switch is turned on. Regardless of the throttle position, the effect will be the same as full throttle.
14. Configurable joystick throttle. A bi-symmetrical 0-5V signal for both forward and reversing.
15. Configurable motor over-temperature detection and protection with the recommended thermistor KTY84-130/150 or KTY83-122.
16. Only support three-phase hall position sensors. Open collector, pull up provided.
17. At Brake analog regen mode, controller needs another analog input as brake input.
18. Enhanced regen brake function. A novel ABS technique provides powerful and smooth regen. The regen can start at any speeds.
19. Cruise control. Only can be activated in forward direction.
20. Bluetooth supported. Required a Bluetooth adapter which needs to be purchased in addition from our website. This adapter is only useful for KLS controller.
21. User customization on the serial port communication is supported.

22. CAN Bus (Optional), broadcast type, with a customizable baud rate (default at 250Khz). CAN bus is not included by default in KLS-RM controllers.
23. Bidirectional anti-slip function (Optional), Prevent the stationary vehicle moving in the opposite direction. After the function enabled, when the controller detects that the motor turns from standstill to the opposite direction, it will drive the motor to provide some braking force, making the vehicle stops or slows down. The braking force can be set as required.
24. Pedal Assist System (Optional), providing assistance to the rider when they pedal.
25. Electric-magnet brake (Optional).
26. Weak Magnetic Speed Boost Function (Optional).
27. Anti-theft function (Optional), an external alarm is required.
28. Built-in DC/DC Module (Optional), to supply external peripherals. (13.5V,2A)
29. Other functions required by the user, require additional customization.

Caution!

For safety reasons, regen must be used together with mechanical brakes.

2.2 Features

1. Enhanced boost current and torque performance.
2. Smart Control with Powerful Microprocessor.
3. Synchronous rectification, ultra-low voltage drop, fast SVPWM and FOC for very high efficiency.
4. Electronic commutation.
5. Monitoring of 3 motor phases, power bus, and power voltage.
6. Monitoring of 12V and 5V voltage sources.
7. Detection of current in all 3 motor phases.
8. Current control loop.
9. Hardware overcurrent protection.
10. Hardware overvoltage protection.
11. Configurable motor current and battery current limits.
12. Low EMC.
13. Battery protection: current reduction, warning, and shutdown at configured high and low voltage levels.
14. The PCB is mounted on an aluminum base plate with a heat sink on the bottom of the controller.
15. Various connector sets which supporting small signals, with waterproof connector set by default.
16. Thermal protection: current reduction, warning, and shutdown at high temperatures.
17. Automatic identification feature for Hall sensors mounted at any angle.
18. Configurable high pedal protection: if high throttle is detected at startup, the controller will not operate.
19. Current multiplication: drawing less current from the battery while outputting more current to the motor.

20. Easy installation: Operates with Just a 3-Wire Potentiometer.
21. Programming via standard PC/laptop, user program provided. Easy to use. No cost to customers.
22. Supports motors with any number of poles.
23. Standard electrical speed up to 70,000 eRPM (electrical speed = mechanical speed * number of pole pairs; number of pole pairs = number of poles / 2).
24. Dust-proof and waterproof under sealed conditions, IP66.

2.3 Specifications

1. Frequency of Operation: 10KHz, 16KHz, 20KHz.
2. Standby Battery Current: < 0.5mA.
3. 5V or 12V Sensor Supply Current: 40mA.
4. Supply(PWR) Current: 30mA Typical.
5. Battery voltage(B+) range: Configurable.
6. Standard Throttle Input: 0-5V(3-wire resistive pot), 1-4V(hall active throttle).
7. Full Power Operating Temperature Range: 0°C to 70°C(MOSFET temperature).
8. Operating Temperature Range: -40°C to 100°C (MOSFET temperature).
9. Max Battery Current: Configurable.
10. Max Motor Current: Configurable.

2.4 Name Regulation

The name regulation of Kelly BLDC motor controllers:

For example: **KLS1270RMO**

KLS: Kelly BLDC motor controller based on sinusoidal waveform which is supposed to work with BLDC motor with three hall sensors. All KLS controllers can do regen brake function by default.

12: 120V battery pack.

70: 700A peak current

RM: Racing motor controller

O: Opto-isolation

Kelly KLS-RM-----Racing Motor controllers					
Model	Nominal Voltage	Max Operating Voltage	Boost Current (20 seconds)	Continuous Current	Continuous Current (liquid cooling)
KLS7225RM	48-72V	36-86V	250A	100A	N/A
KLS7230RM	48-72V	36-86V	300A	110A	N/A
KLS7235RM	48-72V	36-86V	350A	130A	N/A
KLS7240RM	48-72V	36-86V	400A	150A	N/A
KLS7245RM	48-72V	36-86V	450A	160A	N/A
KLS7250RM	48-72V	36-86V	500A	170A	N/A
KLS7260RM	48-72V	36-86V	600A	180A	N/A
KLS8425RM	48-84V	36-100V	250A	100A	N/A
KLS8428RM	48-84V	36-100V	280A	110A	N/A
KLS8430RM	48-84V	36-100V	300A	120A	N/A
KLS8445RM	48-84V	36-100V	450A	160A	N/A
KLS8460RM	48-84V	36-100V	600A	200A	N/A
KLS8480RM	48-84V	36-100V	800A	260A	320A
KLS84100RM	48-84V	36-100V	1000A	280A	400A
KLS84120RM	48-84V	36-100V	1200A	300A	480A

Kelly KLS-RMO-----Opto-isolated Racing Motor controllers					
Model	Nominal Voltage	Max Operating Voltage	Boost Current (30 seconds)	Continuous Current	Continuous Current (liquid cooling)
KLS84150RMO*	48-84V	36-100V	1500A	400A	550A
KLS84180RMO*	48-84V	36-100V	1800A	460A	630A
KLS1270RMO	48-120V	36-138V	700A	230A	280A
KLS1285RMO	48-120V	36-138V	850A	250A	340A
KLS12100RMO	48-120V	36-138V	1000A	280A	400A
KLS12130RMO*	48-120V	36-138V	1300A	340A	500A
KLS12160RMO*	48-120V	36-138V	1600A	400A	5600A
KLS1460RMO	48-144V	36-173V	600A	180A	240A
KLS1475RMO*	48-144V	36-173V	750A	220A	300A
KLS1490RMO*	48-144V	36-173V	900A	280A	360A
KLS14110RMO*	48-144V	36-173V	1100A	320A	400A
KLS14140RMO*	48-144V	36-173V	1400A	380A	490A
KLS1680RMO	48-168V	36-200V	800A	260A	320A
KLS16100RMO*	48-168V	36-200V	1000A	300A	380A
KLS16100RMO*	48-168V	36-200V	1300A	360A	460A
Note * Sealed Aluminium Housing included.					

Chapter 3 Wiring and Installation

3.1 Mounting the Controller

The controller can be placed anywhere but should be kept as clean and dry as possible. If necessary, covering with a cover to prevent water and contaminants from entering.

To ensure full rated output power, the controller should be mounted on a clean, flat metal surface and secured with screws on all four mounting holes. Apply silicone grease or other thermally conductive material to the contact surfaces to enhance thermal performance.

Proper heat sinking and airflow are vital to achieve the full power capability of the controller. The case outline and mounting holes' dimensions are shown below.




Figure 1: KLS7225RM KLS7230RM KLS8428RM
mounting holes' dimensions
(dimensions in millimeters) B+,B-,U,V,W:M6 Bolts




Figure 2: KLS7235RM KLS7240RM KLS8430RM KLS8445RM
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M6 Bolts




Figure 3: KLS7245RM
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M6 Bolts




Figure 1: KLS8425RM
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M5 Bolts




Figure 3: KLS8428RM
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M5 Bolts




Figure 4: KLS8460RM
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M6 Bolts






Figure 4: KLS7250RM KLS7260RM
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M8 Bolts



**Figure 5: KLS8480RM KLS84100RM KLS84120RM
KLS1270RMO KLS1280RMO KLS12100RMO KLS1460RMO**
mounting holes' dimensions
(dimensions in millimeters) B+,B-,U,V,W:M8 Bolts



**Figure 5: KLS8480RM KLS84100RM KLS84120RM
KLS1270RMO KLS1280RMO KLS12100RMO KLS1460RMO**
With Aluminum Liquid Cooling Heatsink at the bottom
mounting holes' dimensions
(dimensions in millimeters) B+,B-,U,V,W:M8 Bolts




Figure 6: KLS-RMO model with Sealed Aluminium Housing
 mounting holes' dimensions
 (dimensions in millimeters) B+,B-,U,V,W:M8 Bolts





Figure 7: Sealed Aluminium Housing with Liquid Cooling Heatsink at the bottom

Mounting holes' dimensions
(dimensions in millimeters) B+,B-,U,V,W:M8 Bolts

3.2 Connections

3.2.1 Pin definition of KLS-RM Controller



DJ7091Y-2.3-11

See from output side

Orange REV-SW (14)	Black GND (6)	White FWD (12)
Red 12V (11)	Yellowish 12V Brake (25)	Blue ECO (22)
Greenish CAN_H (33)	Pink PWR (7)	Brownish CAN_L (34)



DJ7091Y-2.3-21

See from output side

Gray Foot_SW (15)	Green Throttle (3)	
Black GND (20)	D-Gray Meter (8)	
Purple 5V (4)	Brown Brake_AN (2)	Red 12V (11)



DJ7061Y-2.3-21

See from output side

Black GND (21)	Raddle Temp (1)	Purple 5V (5)
Yellow Hall A (18)	D-Green Hall B (17)	D-Blue Hall C (16)

Figure 10: waterproof connector




Figure 11: Compact Connectors




Figure 12: Mini Waterproof Connectors

DJ7091Y-2.3-11 Pin Definition

1. REV_SW(14): Reverse switch input. ※Orange
2. GND(6): Signal return or power supply return. ※Black
3. FWD(12): Forward switch or can be enabled as High speed switch function. ※White
4. 12V(11): 12V Supply. ※Red
5. 12V (25): brake switch. ※Yellowish
6. ECO(22): Low speed switch. ※Blue
7. CAN-H(33): (Optional function). ※Greenish
8. PWR(7): Controller power supply (input). ※Pink
9. CAN-L(34): (Optional function). ※Brownish

DJ7091Y-2.3-21 Pin Definition

1. Foot_SW(15): Throttle switch input. ※Gray
2. Throttle(3): Throttle analog input, 0-5V. ※ Green
3. GND(20): Signal return. ※Black
4. Meter(8): Copied signal of hall-A sensor. ※Dark Gray
5. 5V(4): 5V Supply, <40mA. ※Purple
6. Brake_AN(2): Brake variable regen or Boost function. ※Brown
7. 12V(11): 12V Supply. ※Red

DJ7061Y-2.3-21 Pin Definition

1. GND(21): Signal return. ※Black
2. Temp(1): Motor temperature sensor input. ※Raddle.
3. 5V(5): 5V Supply, <40mA. ※Purple
4. Hall A(18): Hall sensor signal of phase-A. ※Yellow
5. Hall B(17): Hall sensor signal of phase-B. ※Dark Green
6. Hall C(16): Hall sensor signal of phase-C. ※Dark Blue

3.2.2 35pin connector definition




Figure 13: 776164 35pin connector

776164 Pin Definition

01 CTR_PWR(KEY)	02 COIL_RLY-	03 REV_SW	04 FWD_SW	05 12V_OUT
06 TPS2	07 GND	08 VS_5V	09 FOOT_SW	10 12V_OUT
11 CAN_H	12 12V_OUT	13 CTR_PWR(COIL_RLY+)	14 ECO	15 VS_5V
16 SC	17 SA	18 SB	19 ACC_SW	20 TPS
21 TX	22 RX	23 METER	24 ALARM	25 SD
26 BRK_AN/SW	27 GND	28 GND	29 GND	30 MOT_TEMP
31 GND	32 GND	33 GND	34 CAN_L	35 35 GND

- 01 PWR(7): Controller power supply (input).
- 02 Reserved*.
- 03 REV_SW(14): Reverse switch input
- 04 FWD(12): Forward switch or can be enabled as High speed switch function.
- 05 12V(11): 12V Supply.
- 06 Reserved*.
- 07 GND(6): Signal return or power supply return.
- 08 5V(5): 5V Supply, <40mA.
- 09 12V (25): brake switch.
- 10 12V(V+): 12V Supply for Communication Port.
- 11 CAN-L(34): (Optional function).

- 12 12V(11): 12V Supply.
- 13 Reserved*.
- 14 ECO(22): Low speed switch.
- 15 5V(4): 5V Supply, <40mA.
- 16 Hall C(16): Hall sensor signal of phase-C. (This port is reserved on KLS-8080NPS)
- 17 Hall A(18): Hall sensor signal of phase-A. (Also used as Sine signal input on KLS-8080NPS)
- 18 Hall B(17): Hall sensor signal of phase-B. (Also used as Cosine signal input on KLS-8080NPS)
- 19 Foot_SW(15): Throttle switch input.
- 20 Throttle(3): Throttle analog input, 0-5V.
- 21 Tx of Communication Port.
- 22 Rx of Communication Port.
- 23 Meter(8): Copied signal of hall-A sensor.
- 24 Reserved*.
- 25 Reserved*.
- 26 Brake_AN(2): Brake variable regen or Boost function.
- 27-28,31-32: Reserved GND.
- 29 GND(20): Signal return.
- 30 Temp(1): Motor temperature sensor input.
- 33 GND(V-): GND for Communication Port.
- 34 CAN-L(34): (Optional function).
- 35 GND(21): Signal return.

Notes:

1. PWR(7) should be connected to a 12V independent battery or a 12V DC-DC converter
2. All GND pins are internally connected.
3. Meter function is to output signal of hall-A sensor.
4. Three gears and three speeds function can't be used at the same time by default. Because FWD in three gears and High-speed in three speeds are using the same pin (FWD, Pin12).
5. The switch signal is valid at 12V.
6. 12V output (Pin11) can only be used for switch signals, with a total current not exceeding 40mA.
7. CAN bus is not included in KLS-N controller by default.
8. Boost and brake analog regen use the same port on Brake_AN(Pin2). When boost is disabled in user program, Pin2 is used for brake analog regen. When boost is enabled, Pin2 is used for boost function. Due to port conflicts, these two functions can't operate simultaneously on the same port.
9. **Reserved*: Can be customized to implement other functions.**

3.2.3 KLS-RM Controller Standard Wiring




Figure 14: KLS-RM controller standard wiring
(Battery is also used as controller's power supply)

Caution!

Make sure the controller wiring is correct and has been double checked, especially the B+ and the B- of the controller before power on. Wiring faults will damage the controller. Ensure that the B- wiring is securely and properly connected before applying power. The preferred connection of the system contactor or circuit breaker is in series with the B+ line.

Contactors in the B+ line must have a diode across their coils. It was used as freewheel diode. Lacking of this diode may cause serious damage to the power module. Please install this diode as KLS-RM controller standard wiring showing above.

3.2.3 Communication Port

A 4pin connector is provided to communicate with host for calibration and configuration.




Figure 15: SM-4P connector

3.3 Installation Check List

1. Conduct a visual inspection to ensure that components such as mounting holes, wiring, and sealing rings are intact.
2. Check the connection between the battery B+ and NC. For controllers without a fuse, check the connection between the battery B+ and the controller B+ instead of NC.
3. Check the connection between the battery B- and the controller B-.
4. Verify the connections of all signal wires and ensure that their PWR and GND are properly isolated from each other.
5. Check the connection of the motor's Hall wires, the 5V and GND wires should correspond with the motor's interface.
6. Verify the connection of the throttle wires, the 5V and GND wires should correspond with the throttle's interface.
7. Check the connection of the gear wires. It is valid at 12V by default.

Chapter 4 Configuration Program

KLS Configuration program allows users to adjust various parameters according to their needs, enabling the motor to achieve optimal performance. The default parameters may not be suitable for all situations. Please ensure that all parameters are adjusted to appropriate values before testing to avoid any potential dangers. Customers can program using either a PC program or an Android app.

Before operating the motor, an **automatic identification** process **must be performed**. During the process, the controller needs to be connected to the batteries, motor, and throttle. And the PWR (Pin7) needs to be connected with battery B+ to power the controller.

Please perform the automatic identification process according to the automatic identification guide showed in chapter 4.2.

Notes:

1. When configuring existing parameters in the user program or Android app, disconnect the controller from the motor or at least stop the motor.




Figure 16 Warning window

2. The controller may display fault codes when adjusting parameters, but it will not affect programming or configuration. However, it will affect the auto-identification operation, so please try to eliminate error codes before performing the auto-identification operation.
3. Use the RS232-USB cable and SM-4P adapter provided by Kelly to connect to a host computer. During the operation, the PWR of the controller needs to be provided with >+18V (for a 24V controller, provide >+8V). Connect the GND to battery B-.
4. To connect to Android devices, KLS controller requires a bluetooth adapter.

4.1 Connecting to upper host.

You have three ways to connect the controller to host computers or Android devices:

1. Using Kelly USB cable, connect SM-4P (Female) from controller to the USB port on computer. You may download Kelly USB Cable driver or at our website.

(<https://media.kellycontroller.com/new/CH341SER.zip>)



Figure 17: Kelly USB Cable

2. Using RS232-USB cable along with SM-4Pin adapter, connect SM-4Pin (Female) from controller to the USB port on computer. You may download USB-RS232 driver at our website. (<https://media.kellycontroller.com/new/USB-CONVERTER-RS232-Win10.zip>)



Figure 18: RS232-USB (left) and SM 4-Pin (right) adapter

3. Using Bluetooth adapter. Connect it to SM-4P (Female) then connect the controller to Android devices through Bluetooth. This Bluetooth adapter can be purchased from our website. (<https://kellycontroller.com/shop/usb-adapter>)



Figure 19: Bluetooth Adapter

4.2 How to use auto-Identification.

Here is a brief overview of the automatic identification process:

1. Connect the controller and the motor according to the **standard wiring diagram (Figure 11)**. Please make sure there is no load on the motor shaft before starting the programming.
2. Connect the controller to PC by using a Kelly USB cable or an USB to RS232 set.
For Android devices, please use the Bluetooth adapter to connect the controller.
3. Download the corresponding USB drivers and the user program from our website, only one driver can be installed, two drivers installed at same time are incompatible. After the USB driver is successfully installed, please restart your C.
4. Turn the key switch to supply power to the controller from B+/B- and PIN7, then open the user program on your device. Click the 'READ' button to open the initial interface as the figure below.

Motor ETS

File User

RS232 Config

Baud rate 19200 Stop bit 0 Data bits 8 parity non COM COM1 ☒ Auto connection State COM14 Open Close

Workspace

Module Name	RLS7218W	Brake Dead Low	20	BRK_AD Brk %	0	Resolver Poles	2	Forward HA	2	☒ Startup H-Pedel
User Name	bzbb	Brake Dead High	80	Anti-theft	15	Min Excitation	0	Reverse HA	6	☐ Brake H-Pedel
Serial Number	17280397	Max Output Fre	1000	Brk_Speed Limit	50	Motor Temp	0	Reverse HA	1	☐ NTL H-Pedel
Software Version	02060006	Max Speed	4000	RLS_TPS Brk %	0	High Temp Cut °C	130	Brake_SW_Level	1	☒ Joystick
Controller Volt	72	Max Fwd Speed %	100	NTL Brk %	0	Resume °C	110	J CAN Address	5	☒ Three Gears Switch
Low Volt	50	Max Rev Speed %	50	Accel Time	10	High Temp Str°C	100			☐ Boost
Over Volt	80	MidSpeed Forw	50	Accel Rls Time	5	High Temp Week %	0			☐ Foot Switch
Hall	430	MidSpeed Rev	30	Brake Time	5	Line Hall Zero	508			☒ SW Level
PhaseCurr Max AD	340	LowSpeed Forw	50	Brake Rls Time	1	Line Hall	410			☒ 0, HDM: 1, KIM
Motor_Current%	100	LowSpeed Rev	30	BRK_SW Brk %	10	Line Hall High	972			☐ Cruise
Battery_Current%	50	Three Speed	0	Change Dir Brk%	0	Line Hall Low	50			☐ Anti-theft
Identify Angle	85	PWM frequency	16	Compensation	20	Swap Motor Phase	0			☒ Anti-Slip
TFS Low Err	0	IQ Kp	500	IVT BRK Max	50	Resolver init	8129			☐ Change Direction
TFS High Err	95	IQ Ki	10	IVT BRK Min	50	0° Hall value	3			
TFS Type	2	ID Kp	1500	Torque Speed Kp	2000	60° Hall value	1			
TFS Dead Low	20	ID Ki	30	Torque Speed Ki	60	120° Hall value	5			
TFS Dead High	80	HS_ACQR_Kp	2000	Speed Err Limit	1000	180° Hall value	4			
TFS Fwd MAP	30	HS_ACQR_Ki	60	Motor Nominal	80	240° Hall value	6			
TFS Rev MAP	20	HS_ACDR_Kp	5000	Motor Poles	8	300° Hall value	2			
Brake Type	0	HS_ACDR_Ki	100	Speed Sensor	2	Forward HA	5			

Note: Please read the parameters for the first time, on the whole parameters for screenshots to save the page. According to the records when parameters of the garbled words can restore.
Note: The mouse hover will display each parameter interpretation, please input data according to clew, don't exceed the scope of data.

ReadZero

Write

Figure 20: User program initial interface

Please check whether the value of Identification_Angle is at 85. The 85 means this controller had finished the automatic identification operation with the motor in factory before. It is still needed to run automatic identification operation before running.

5. Fill 170 in the Identification_Angle value. Then click the write button. The user program will give a pop-up window which shows the Write operation is succeeded. Then exit from the user program and turn off the power supply.
6. Turn on the power supply after the power supply is off for a few seconds. The motor shaft

will try to run on random directions. This is a normal operating phenomenon.

7. Wait about 2-3 minutes.
8. The error indicator will show error code 3-2, means automatic identification operation is finished normally. And you will see reset error message in the monitor screen of user program.
9. Turn off the power supply again, then wait about a few seconds to turn on the power supply again.
10. Connect the controller to user program. You will see 85 in the Identification_Angle. Means, the controller auto-identification operation is succeeded. The motor is ready to run.
11. If Identification_Angle value is 170, it means that auto-identification is still in progress.
12. If no error code is triggered, please do not manually write 85 to Identification_Angle or restart the power supply.
13. If a constant error code lasts above 5 minutes and there are other error codes such as Identify error, hall error etc, please return to the initial interface of user program and write 85 to Identification_Angle manually.
14. Before turn off the power supply ,make sure that Identification_Angle is not at 170. Otherwise the controller will try to keep doing identification operation all the time after you turn on power supply again. When the error codes occur, please quit from user program and try step 6 again.
15. After successful identification, make sure that Identification_Angle is not at 170. Then you may turn on the power supply.
16. If the direction of the motor is not what you expected, there is no need for you to operate again, just check the Change Direction option in the last part of initial interface then click Write button and reset, the motor will run on the opposite direction.

4.3 Program parameters and value

On program's initial interface, these items are listed:

Number	Parameter	Possible Value	Default Value	Description	Source of Value*
1	Model Name			Controller Model.	Default
2	User Name			User code, to identify controller variants.	Default
3	Serial Number			Serial Number.	Default
4	Software Version			Software Version.	Default
5	Controller Volt	0-144		Controller Voltage(V).	Default
6	Low Volt	18-180		Minimum normal voltage(V), In order to protect the battery, if the battery voltage is lower than this value, the controller will not work.	User Configuration
7	Over Volt	18-180		Maximum normal voltage(V), In order to protect the battery, if the battery voltage is higher than this value, the controller will not work.	User Configuration
8	Hall	0-1000		Hall Galvanometer Rate(A).	Default
9	PhaseCurr Max AD	409-2048		The Max AD value of phase current.	Default
10	Motor_Current	20-100%	100%	The ratio range of the motor phase current to the controller peak current.	User Configuration
11	Battery_Current	20-100%	50%	Maximum battery current. Used to set the upper limit of battery current to protect the battery. A lower value will limit the battery output current more and protect the battery more effectively. However, if this value is too low, it will affect acceleration.	User Configuration
12	Identify Angle	85 / 170	85	Status of identification: 85:normal operation. 170: A reboot is required to automatically identify the sensor angle. Once identification is complete, this value will be reset to 85.	Auto
13	TPS Low Err	0-20%	0%	Hall pedal parameter, only valid when TPS type is set to 2. When the actual value is lower than this value, the controller will report a TPS type error, 20%*5V=1V	User Configuration
14	TPS High Err	80-100%	95%	Hall pedal parameter, only valid when TPS type is set to 2. When the actual value is higher than this value, the controller will report a TPS type error, 80%*5V=4V	User Configuration

15	TPS Type	1 / 2	1	Throttle Type, 1: 0-5K,resistance pedal; 2: 0,5V,Hall active pedal;	User Configuration
16	TPS Dead Low	0-60%	20%	Throttle Dead Zone Lower Limit, 20%*5V=1V.	User Configuration
17	TPS Dead High	60-95%	80%	Throttle Dead Zone Higher Limit, 80%*5V=4V.	User Configuration
18	TPS Fwd MAP	0-100%	30%	When moving forward , the MAP value corresponding to throttle midpoint, to adjust throttle response amplitude.	User Configuration
19	TPS Rev MAP	0-100%	20%	When moving backward , the MAP value corresponding to throttle midpoint , to adjust throttle response amplitude.	User Configuration
20	Brake Type	0 / 1 / 2	0	Regen braking mode 0: Switch regen mode. 1:0-5K, resistance pedal regen. 2:0-5V, hall active pedal regen.	User Configuration
21	Brake Dead Low	5-40%	20%	Brake Dead Zone Lower Limit, 20%*5V=1V.	User Configuration
22	Brake Dead High	60-95%	80%	Brake Dead Zone Upper Limit, 80%*5V=4V.	User Configuration
23	Max Output Fre	50-1200	1000	Max output Frequency(Hz).	User Configuration
24	Max Speed	0-16000	4000	Motor max speed (RPM).	User Configuration
25	Max Fwd Speed	0-100%	100%	Maximum forward speed to the motor max speed .	User Configuration
26	Max Rev Speed	0-100%	100%	Maximum reverse speed to the motor max speed.	User Configuration
27	MidSpeed Forw Speed	0-100%	50%	Maximum forward speed in the middle speed gear .	User Configuration
28	MidSpeed Rev Speed	0-100%	30%	Maximum reverse speed in the middle speed gear .	User Configuration
29	LowSpeed Forw Speed	0-100%	50%	Maximum forward speed in the low speed gear .	User Configuration
30	LowSpeed Rev Speed%	0-100%	30%	Maximum reverse speed in the low speed gear .	User Configuration
31	Three Speed	0 / 1 / 2	0	Number of speed modes: 0: one speed mode: maximum speed mode. 1:two speed modes: middle speed mode and maximum speed mode . 2:three speed modes:low speed mode, middle speed mode and maximum speed mode.	User Configuration

32	PWM frequency	10 / 16 / 20	16	PWM modulation frequency (Khz)	User Configuration
33	IQ K_p	0-32767	500	K_p of Q-ring, the proportional gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will accelerate the response speed but will increase startup jitter; decreasing this value will reduce startup jitter but will also decrease the response speed.	User Configuration
34	IQ K_i	0-32767	10	K_i of Q-ring, the integral gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will improve current accuracy but will increase startup jitter and instability. Decreasing this value will enhance stability and reduce startup jitter but will also lower current accuracy.	User Configuration
35	ID K_p	0-32767	1500	K_p of D-ring, the proportional gain in D-ring speed loop, is mainly effective at speeds below 400 RPM. Increasing this value will accelerate the response speed but will increase high-speed jitter; decreasing this value will reduce high-speed jitter but will also decrease the response speed.	User Configuration
36	ID K_i	0-32767	30	K_i of D-ring, the integral gain in D-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will improve speed accuracy but will increase high-speed jitter and instability. Decreasing this value will enhance stability and reduce high-speed jitter but will also lower speed accuracy.	User Configuration
37	HS_ACQR_ K_p	0-32767	2000	K_p of Q-ring, the proportional gain in Q-ring current loop, is mainly effective at speeds above 400 RPM. Increasing this value will accelerate the response speed but will increase startup jitter; decreasing this value will reduce startup jitter but will also decrease the response speed.	User Configuration
38	HS_ACQR_ K_i	0-32767	60	K_i of Q-ring, the integral gain in Q-ring current loop, is mainly effective at speeds above 400 RPM. Increasing this value will improve current accuracy but will increase startup jitter and instability. Decreasing this value will enhance stability and reduce startup jitter but will also lower current accuracy.	User Configuration
39	HS_ACDR_ K_p	0-32767	5000	K_p of D-ring, the proportional gain in D-ring speed loop, is mainly effective at speeds above 400 RPM. Increasing this value will accelerate the response speed but will increase high-speed jitter; decreasing this value will reduce high-speed jitter but will also decrease the response speed.	User Configuration
40	HS_ACDR_ K_i	0-32767	100	K_i of D-ring, the integral gain in D-ring current loop, is mainly effective at speeds above 400 RPM. Increasing this value will improve speed accuracy but will increase high-speed jitter and instability. Decreasing this value will enhance stability and reduce high-speed jitter but will also lower speed accuracy.	User Configuration

41	BRK_AD Brk	0-50%	0%	Brake pedal regen's regen strength, 0= no regen.	User Configuration
42	Anti-theft	0-30%	15%	When the anti-theft function is activated, the percentage of the motor's locking current to the maximum current.	User Configuration
43	Brk_Speed Limit	0-500	0	Minimum motor speed to activate regen brake (RPM), RPM below this value will exit regen.	User Configuration
44	RLS_TPS Brk	0-50%	0%	Pedal releasing regen 's regen strength, 0= no regen.	User Configuration
45	NTL Brk	0-50%	0%	Neutral gear regen 's regen strength, 0= no regen.	User Configuration
46	Accel Time	1-250	5	Torque mode accelerate Time, the time of torque from 0 to max,(X0.1second)	User Configuration
47	Accel Rls Time	1-250	1	Torque mode accelerate release delay Time, the time of torque from max to 0,(X0.1second)	User Configuration
48	Brake Time	1-250	5	Torque mode Brake Time, the time of Brake Torque from 0 to max,(X0.1second)	User Configuration
49	Brake Rls Time	1-250	1	Torque mode Brake release Time, the time of Brake Torque from max to 0,(X0.1second)	User Configuration
50	BRK_SW Brk	0-50%	10%	Switch regen 's regen strength. 0= no Switch regen.	User Configuration
51	Change Dir Brk	0-50%	5%	Change direction regen's regen strength. 0= no Change direction regen.	User Configuration
52	Compensation	0-100%	20%	Compensation current of anti-slip function.	User Configuration
53	IVT BRK Max	0-10000	10000	Maximum motor speed for enable Change direction regen(RPM)	User Configuration
54	IVT BRK Min	0-5000	50	Minimum motor speed for enable Change direction regen (RPM)	User Configuration
55	Torque Speed K_p	0-10000	3000	K_p of Q-ring in torque mode, the proportional gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will accelerate the response speed but will increase startup jitter; decreasing this value will reduce startup jitter but will also decrease the response speed.	User Configuration
56	Torque Speed K_i	0-500	80	K_i of Q-ring in torque mode the integral gain in Q-ring current loop, is mainly effective at speeds below 400 RPM. Increasing this value will improve current accuracy but will increase startup jitter and instability. Decreasing this value will enhance stability and reduce startup jitter but will also lower current accuracy.	User Configuration

57	Speed Err Limit	50-4000	1000	Limit of K_p and K_i in torque mode, need to be adjusted at same time when adjusting K_p and K_i in torque mode.	User Configuration
58	Motor Nominal	0-1000	80	Motor Current when identification(A)	User Configuration
59	Motor Poles	2-128	8	Number of motor poles, equal to 2* pole pairs. When used for hub motors, reducing this value by multiples, such as from 8 to 4, can improve the speed measurement accuracy.	User Configuration
60	Speed Sensor Type	2 /3/ 4	2	Sensor Type: 2. Hall sensor 3. Magnetic encoder.	User Configuration
61	Resolver Poles	2-32		Reserved.	User Configuration
62	Min Excitation	0-100	0	Minimum excitation coefficient (A) This value affects the current and maximum speed of the motor when the field weakening function is enabled. When this value = 0, the field weakening function has no actual effect	User Configuration
63	Motor Temp	0 / 1 / 2	0	Temperature sensor type, 0:none. 1: KTY84-130 and KTY84-150 2: KTY83-122	User Configuration
64	High Temp Cut °C	60-170	150	Temperature for triggering the motor's high temperature cut off.	User Configuration
65	Resume °C	60-170	110	When the temperature drops back to this value, high temperature resume will be triggered.	User Configuration
66	High Temp Str°C	0-170	100	starting temperature for high-temperature weakening. (°C)	User Configuration
67	High Temp weak	0-100%	50%	The strength of high-temperature weakening (%)	User Configuration
68	Line Hall Zero	1-1023		Zero point of sine/cosine sensor signal, this value / 1024 * 5 = actual voltage value (Volts). Available for sine/cosine sensor	User Configuration
69	Linear Hall Amplitude	1-1024		Signal amplitude of sine/cosine sensor signal. this value / 1024 * 5 = actual voltage value (Volts). When this value is below 153.6 or above 256,the signal voltage is error. Available for sine/cosine sensor	User Configuration

70	Line Hall High	1-1023		An error will be reported when the amplitude of the sine/cosine sensor signal exceeds this value. this value / 1024 * 5 = actual voltage value (Volts). Available for sine/cosine sensor	User Configuration
71	Line Hall Low	1-1023		An error will be reported when the amplitude of the sine/cosine sensor signal is below this value. this value / 1024 * 5 = actual voltage value (Volts). Available for sine/cosine sensor	User Configuration
72	Swap Motor Phase	0 / 1 /255	0	Swap phase function status 0: disabled 1: enabled, 255: error. Available for sine/cosine sensor	Default
73	Synchro Initial Angle	0-65535	8192	Synchro Initial Angle , defines the reference point of the position when sensor type is set to 4. Available for sine/cosine sensor	Default
74	0° Hall value	0-7	2	Hall sensor sequence value at motor electrical angle 0°.	Auto
75	60° Hall value	0-7	6	Hall sensor sequence value at motor electrical angle 60°	Auto
76	120°Hall value	0-7	4	Hall sensor sequence value at motor electrical angle 120°	Auto
77	180°Hall value	0-7	5	Hall sensor sequence value at motor electrical angle 180°	Auto
78	240°Hall value	0-7	1	Hall sensor sequence value at motor electrical angle 240°	Auto
79	300°Hall value	0-7	3	Hall sensor sequence value at motor electrical angle 300°	Auto
80	Forward HA Rising edge	0-7	6	Forward Hall-A Rising edge sequence value	Auto
81	Forward HA Falling edge	0-7	1	Forward Hall-A Falling edge sequence value	Auto
82	Reverse HA Rising edge	0-7	5	Reverse Hall-A Rising edge sequence value	Auto
83	Reverse HA Falling edge	0-7	2	Reverse Hall-A Falling edge sequence value	Auto
84	Brake_SW_Level	0-255		Brake_SW_Level	Default
85	J CAN Address	0-255	5	CAN Address, when there are multiple CANs, different addresses need to be set	User Configuration
86	Startup H-Pedal	checked/ unchecked	checked	Startup High pedal function , Checked: From powerup, when the first time throttle being pressed, the controller will report a high pedal error to prevent accidental starting, need to step on the pedal again to start.	User Configuration
87	Brake H-Pedal	checked/ unchecked	unchecked	Brake High-pedal function Checked: When press the brake and throttle at the same time, he controller will report a high pedal error to stop running.	User Configuration

88	NTL H-Pedal	checked/ unchecked	unchecked	Neutral High-pedal function Checked: the first time throttle being pressed after switching gears, the controller will report a high pedal error to prevent accidental starting, need to step on the pedal again to start.	User Configuration
89	Joystick	checked/ unchecked	unchecked	Joystick throttle Checked: enable joystick throttle, Its range: 0-2.5V: forward 2.5V: neutral 2.5V-5V: backward. Has same range of dead zone as TPS dead zone.	User Configuration
90	Three Gears Switch	checked/ unchecked	unchecked	Three-gear function Check: Enable three operating gears: Forward, Neutral, Reverse. Uncheck: Forward only.	User Configuration
91	Boost	checked/ unchecked	unchecked	Boost function, Checked: enable boost switch, Connect Brake_AN (PIN2) to 12V to start boost. Unchecked: Connect Brake_AN (PIN2) to 12V to start switch regen.	User Configuration
92	Foot Switch	checked/ unchecked	unchecked	Throttle switch Checked: Connect Foot_SW to 12V to enable throttle, so motor can start.	User Configuration
93	SW Level	checked/ unchecked	checked	Defining which is the effective level of the switch. Checked: high level=enable. Unchecked: low level=enable.	Default
94	0,HIM;1,KIM	checked/ unchecked	checked	Controller type Checked: KIM. Unchecked: HIM.	Default
95	Cruise	checked/ unchecked	unchecked	Cruise function Check: Enable the cruise function. Press and hold the accelerator for more than 3 seconds to enter the cruise mode. If the eRPM is lower than 4000, the controller will automatically exit the cruise mode.	User Configuration
96	Anti-theft	checked/ unchecked	unchecked	Anti-theft function Checked: enable anti-theft function, Need to connect to external anti-theft device. When the alarm is triggered, the motor will resist being turned.	User Configuration

97	Anti-Slip	checked/ unchecked	unchecked	Anti-Slip function Checked: enable anti-slip function, The motor will resist rotation to prevent the vehicle from moving due to external forces.	User Configuration
98	Change Direction	checked/ unchecked	unchecked	Change Direction function Checked: Swap the forward and backward directions. Unchecked: no swap. Used to correct the motor from moving opposite direction after identification	User Configuration

Source of Value *:

1. User : Users should modify these values to adjust the controller.
2. Auto: These values are generated by the sensor or the controller's program, and users can affect the operation of the controller by modifying these values.
3. Default: These values are factory presets or sensor readings , cannot be modified by the user program.

Chapter 5 Maintenance

Caution!

There are no user-serviceable parts inside the controller. Do not attempt to open the controller on your own, as this will void your warranty.

The exterior of the controller should be cleaned periodically.

The controller is a high powered device. When working with any battery powered vehicle, proper safety precautions should be taken that include, but are not limited to proper training, wearing eye protection, avoidance of loose clothing, hair and jewelry, using insulated tools.

Although the controller virtually requires no maintenance after proper installation, it is recommended to follow these steps during use:

1. Disconnect the battery, starting with the positive terminal, to cut off the power.
2. Discharge the capacitors in the controller by connecting a load (such as a contactor coil, resistor, or horn) across the controller's B+ and B- terminals.
3. Regularly remove any dirt or corrosion from the bus bar area. Wipe the controller with a moist rag and ensure it is completely dry before reconnecting the battery.
4. Make sure the connections to the bus bars are tight. To avoid physically stressing the bus bars, use two well-insulated wrenches for the operation.
5. Fanned model require routine fan maintenance, including ensuring the fan rotate normally and cleaning the dust on the fan.

Table 1: Error Codes

Error Codes

Error code		Explanation	Solution
1, 1	□ □	Auto-Identification failed	1. Check Phase line or Hall line. 2. Check Hall power line(+5V and GND). 3. The motor load maybe too high. Please unload the motor before proceeding with identification.
1, 2	□ □□	Over voltage error	1. Battery voltage is too high for the controller. Check battery volts and controller configuration. 2. Regeneration over-voltage. Controller will limit regen or stop regen. please reduce the regen ratio in configuration.
1, 3	□ □□□	Low voltage error	Battery voltage is too low, please check the battery and recharge. When the battery voltage continuously exceeds the low voltage cut-off value for 5 seconds, the controller will resume normal operation.
1, 4	□ □□□□	The controller did not receive CAN commands	Resend CAN commands from VCU.
2, 1	□□ □	Motor stall	The motor did not reach 25eRPM within 2 seconds of starting. Please check the Hall signal lines and the phase line connections.
2, 2	□□ □□	Internal voltage error	1. Check the connection between PWR and B+(For 8080N series, check connection between PWR and +12V; GND and -12V). 2. The load on the 5V or 12V power supply could be too heavy, ensure that the measured voltage of the 5V power supply is not less than 4V and the voltage of the 12V power supply is not less than 8V. The lower these values are, the heavier the load on the power supply. 3. If none of the above issues are present, the internal power module of the controller may be damaged. The controller needs to be sent back to the factory.
2, 3	□□ □□□	Over temperature	The controller temperature is too high, about to stop. Please wait until it restore to 80℃.
2, 4	□□ □□□□	Throttle error at power on	Throttle signal is higher than the value of "TPS_dead_low"at power-on. Release the throttle and press again or adjust the TPS_dead_low value. If still can't fix the issue, check if the throttle

			is functioning properly.
3, 1	0000 0	Reserved	
3, 2	0000 00	Internal reset error	Current is too high or current fluctuations are too large. Reduce the phase current and check if the 5V and 12V power supplies are normal.
3, 3	0000 0000	Hall throttle is open or short-circuit	May occur after TPS_Type being set to 2. 1. The throttle might have an internal short circuit or the ground wire might be disconnected. 2. Set TPS_High_Err to 95 , check the throttle and its wiring, then restart to fix the issue.
3, 4	0000 00000	Angle sensor error	1. Speed sensor type error,customers may set the correct sensor type through user program or App. 2. Incorrect wiring. 3. Speed sensor is damaged or defective. Or feedback signal is erratic.
4, 1	00000 0	Switch-direction error	1. Throttle is not at 0 when switching motor direction. 2. Motor rotation speed is above 50RPM.
4, 2	00000 00	Reserved	
4, 3	00000 0000	Motor over-temperature	May occur after motor temp being set to 1 or 2. The Motor temperature has exceeded the configured maximum value. The controller will shut down until the motor temperature cools down.
4, 4	00000 00000	Hall Galvanometer sensor error	Hall galvanometer inside the controller is damaged.
Error codes can be read through PC software or Android app.			

Contact Us:

Kelly Controls

Home Page:

<http://www.KellyController.com>

Download user manual, instructions and user program:

<https://kellycontroller.com/support/>

E-mail:

Sales@Kelly-Controls.com

Phone:

(01) 224 637 5092